

Interval File Format

File Title	Description
OPERATING_COMPANY_CODE	Operating Company Code
customer_number	Customer Number
date	Date
est_hb_0000	Interval Usage from 0001 - 0100
est_hb_0100	Interval Usage from 0101 - 0200
est_hb_0200	Interval Usage from 0201 - 0300
est_hb_0300	Interval Usage from 0301 - 0400
est_hb_0400	Interval Usage from 0401 - 0500
est_hb_0500	Interval Usage from 0501 - 0600
est_hb_0600	Interval Usage from 0601 - 0700
est_hb_0700	Interval Usage from 0701 - 0800
est_hb_0800	Interval Usage from 0801 - 0900
est_hb_0900	Interval Usage from 0901 - 1000
est_hb_1000	Interval Usage from 1001 - 1100
est_hb_1100	Interval Usage from 1101 - 1200
est_hb_1200	Interval Usage from 1201 - 1300
est_hb_1300	Interval Usage from 1301 - 1400
est_hb_1400	Interval Usage from 1401 - 1500
est_hb_1500	Interval Usage from 1501 - 1600
est_hb_1600	Interval Usage from 1601 - 1700
est_hb_1700	Interval Usage from 1701 - 1800
est_hb_1800	Interval Usage from 1801 - 1900
est_hb_1900	Interval Usage from 1901 - 2000
est_hb_2000	Interval Usage from 2001 - 2100
est_hb_2100	Interval Usage from 2101 - 2200
est_hb_2200	Interval Usage from 2201 - 2300
est_hb_2300	Interval Usage from 2301 - 2400